

# 713 - OVEN CLEANER CREAM

OVEN CLEANER is biodegradable, non-etching and traditional cleaner for baking and roasting oven. Oven Cleaner dissolves grease and burnt-in food residues inside the oven. It is well suited for cleaning of grills and baking plates.

## Instructions

Apply with a brush or cloth on a cold surface. Close the oven and heat to 200-250°C (400-480°F) for 20 min. When the oven is cold, wash with cold water. Surfaces with heavy contamination may require repeated treatment.

## Declaration

Contains: <15% anionic surfactants, <5% amphoteric and nonionic surfactants. Contains also: water, potash and perfum.

**WARNING:** Do not use the cleaner on the self-cleaning oven panels. Keep out of reach of children.



## Conditioning

250ml (12 units/box) / 500ml (12 units/box)

If you have any questions, please contact our Technical Department on: +45 4817 6970