

719 - OVEN CLEANER SPRAY

OVEN CLEANER SPRAY is special formulated for cleaning of baking and roasting ovens as well as for barbeque grills. Oven Cleaner Spray efficiently dissolves grease and burnt-in food residues inside the oven. It is well suited for cleaning of grills and baking plates.

Instructions

Heat up the oven to max. 50°C and let cool down for 10-15 min. Spray the cleaner on the surface in an even thin layer. After 10 min. of reaction-time, the surface is cleaned with a scouring sponge and clean water. Wash again carefully with clean water. Heavy contaminated areas may require a second treatment. May attack linoleum, aluminium and painted surfaces. Do NOT use on self-cleaning panels or spray on the fan-area of a hot-air oven.

Declaration

Contains: <15% Sodium-hydroxide, <15% non- ionic surfactants.
Also contains: water and isopropyl alcohol.

DANGER: Corrosive: Causes severe skin burns and eye damage. Do not breathe spray. Wash skin thoroughly after handling. Wear suitable gloves and eye/face protection. Keep out of the reach of children.

IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.

IF ON SKIN: Take off immediately all contaminated clothing. Rinse skin with water.

IF INHALED: Remove person to fresh air and keep comfortable for breathing.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor.



Conditioning

500ml (12 units/box)

If you have any questions, please contact our Technical Department on: +45 4817 6970